



711205 QUICK-TRIM™ END TRIM PACKAGE INSTALLATION INSTRUCTIONS

1. Insert mounting bracket into end of track with washer and nut to the outside surface of the track slot.
2. Tighten nut onto bolt, keeping flat surface of bracket flush with end of track.
3. Screw end trim plate to bracket with 1/4" tapping screw.

