



# SINGLE-STRAP TROLLEY HANGER INSTALLATION INSTRUCTIONS

711221- DELRIN | 643427 - STEEL

Bore a 7/8" hole 1-1/4" on center from top of door. Then saw down to hole per dotted lines in front - view A. Assemble parts per end view B. Fit this assembly snugly to top of door and while firmly in place, locate and drill bolt holes through holes in face of strap. Bolt the assembly to door.

Attach truck, mount door track as described below and hang door. Make vertical and lateral adjustments and adjust hex jam nut.

