



VENT DOOR OPERATOR INSTALLATION INSTRUCTIONS

NO. 712125 (18") | NO. 712126 (24") | NO. 712127 (36")

First attach operator bar hinge to bottom of vent panel. Locate directly between two latch handles in center of panel. Make sure hinge pin is flush with edge of panel frame. (See Figure A). Use two No. 8 wood screws provided.

With panel latched in closed position, swing mounting channel into place on inside of jamb frame and attach with two No. 12 drilling screws.

